



Position	Code	description
	9811040850	SCREW
	9815002850	INOX NUT M10 X 1.25 (BOILER/TAP)
	9815003750	INOX NUT M8 X 1 (BOILER/JUNCTION)
	5332180400	SLIDING BLOCK BLACK(PA66)
0	5313270059	HEATING ELEMENT SEAL
001	5332112700	COVER
002	5332169200	MEASURING SPOON
003	5532109600	KNOB
004	5332124000	COVER
005	512302	WARNING LIGHT
006	5118100800	WARNING LIGHT
007	5932105600	CONTROL PANEL
008	6113211791	SPRING
009	5532107500	KNOB
010	512641	Green Warning Light
010	ES000	*NOT AVAILABLE
011	5513200029	Change Over Switch
012	607529	BRACKET
013	5513200209	TAP
014	511816	FUSE
015	5232101300	THERMOSTAT 125°
016	5232100600	THERMOSTAT 105°
017	536281	TUBE
018	9810153031	SCREW
019	6813210411	BOILER UPPER
020	9816100523	NUT
021	533216	GASKET
022	5132109800	HEATING Element
023	6032107100	DIFFUSER
024	7313285849	GASKET
025	7313286109	SUPPORT
026	9850081500	WASHER
027	6213210431	CONNECTION
028	5313217701	O-RING D=3,85
029	6132101300	CLIP
030	534710	GASKET
031	6132101400	SPRING

032	5332118000	TUBE
033	5513220521	FILTER
034	535926	TUBE
035	534848	SUPPORT
036	5113211291	PUMP
037	5532112000	TUBE
038	7313286129	VALVE
039	5332113500	HINGE
040	5332116100	TUBE
041	6132101000	SPRING
042	7313286139	BOILER
043	7313271639	TANK
045	5332148400	VALVE
046	621986	RING
047	6213210451	DOWEL
048	6032101600	BRACKET
049	6113211931	SPRING
050	5332149900	TUBE UPPER
051	5313217761	O-RING
052	5332113800	TUBE LOWER
053	5313217741	O-RING
054	5332229600	COVER
055	5332131300	CONNECTION H2O
056	5332117200	PRESSING DEVICE
057	5332118600	INSERT
058	7032102400	CUP PLATE
059	5332130000	TRAY
060	532233	RUBBER PAD
063	5532106300	BOTTOM
064	533921	WIRE CLAMP
065	5332123800	BODY
066	5332108700	GASKET
067	5332109000	PISTON
068	6132100800	SPRING
069	5332111600	O-RING
070	7313280779	SUMP
071	7313285889	FILTER
072	7313285949	Large two-cup filter

073	6032107200	FILTER
074	534714	LEVER
075	7313285819	Large two-cup filter
076	7313285829	Small one-cup or pod filter