



Position	Code	description
001	532233	RUBBER PAD
002	5532112800	SUPPORT BASE + RUBBER PAD
004	7313286029	HEATING Element
005	5232100000	THERMOSTAT
006	5513225161	PCB
007	7313276649	TUBE
008	6132100300	SPRING
009	7032101000	PLATE
010	5332102900	GASKET
011	5332183600	SUPPORT
012	SER1015	FUSE
013	5332128900	COVER
014	5513200149	FILTER
015	5332152300	HINGE
016	7313280379	POWER SUPPLY CORD
017	5332128200	COVER
018	5332128700	PIN
019	5332128800	KNOB
020	6132102300	SPRING
021	5332129300	DISCHARGE PIPE
022	7313285829	Small one-cup or pod filter
023	5113211501	PUSH BUTTON
024	9810153031	SCREW
025	6032107200	FILTER
026	5332131100	TUBE
027	5332130900	TUBE
028	5332129900	CONNECTION
029	7313280839	TANK
030	5332129200	HANDLE
031	5513200119	COVER
032	5332129000	TUBE
033	5332144800	O-RING D=6
034	5332108700	GASKET
035	535692	O-RING
036	5332113800	TUBE LOWER
037	533135	O-RING
038	5332117200	PRESSING DEVICE

039	5332229600	COVER
040	6132101400	SPRING
041	5332131300	CONNECTION H2O
042	5332118000	TUBE
043	5913215511	DOOR
044	5513200129	PORTAFILTRO
045	6132100000	SPRING
046	5332100100	GASKET
047	537243	LEVER
048	5332118600	INSERT
049	5332122900	FLOAT
050	7032104300	CUP PLATE
051	5332128000	TRAY
052	5332125200	TUBE
053	5513220521	FILTER
054	5332122800	TUBE
055	534848	SUPPORT
056	5113211281	PUMP
057	5332129400	SPONGE
058	5232100600	THERMOSTAT 105°
059	6132101300	CLIP
060	7313286129	VALVE
061	536321	TUBE
062	9850081500	WASHER
063	6213210431	CONNECTION
064	5532108300	TUBE L=240
065	511816	FUSE
066	536281	TUBE
067	5232101300	THERMOSTAT 125°
068	607529	BRACKET
069	5532109600	KNOB
070	534714	LEVER
071	5513200399	TANK
072	5332128300	HANDLE
073	5332111600	O-RING
074	534714	LEVER
075	5332109000	PISTON
076	7313285889	FILTER

077	7313285949	Large two-cup filter
078	7313285819	Large two-cup filter
079	7313280779	SUMP
080	5332169200	MEASURING SPOON
081	5213218991	PCB
082	5113210841	Change Over Switch
083	5118100800	WARNING LIGHT
084	6113211791	SPRING
085	5532106200	KNOB
086	534710	GASKET
087	512641	Green Warning Light
088	5513200209	TAP
089	5913215821	CONTROL PANEL
090	6813210411	BOILER UPPER
091	5313238651	INSERT
092	5332135800	PUSH BUTTON PANEL
093	5313217701	O-RING D=3,85
094	533216	GASKET
095	7313285929	HEATING Element
096	7313286139	BOILER
097	6032107100	DIFFUSER
098	7313285849	GASKET
099	7313286109	SUPPORT
100	5332148400	VALVE
101	621986	RING
102	6113211931	SPRING
103	6213210451	DOWEL
105	7313281249	CARAFE
106	9816100523	NUT