



Position	Code	description
	5313226131	SWITCH HOLDER
	5332283000	GLASS DISPENSER BLACK(ABS) (4E)MCSA
	5332108700	GASKET
	7313217261	ASS. GRINDS (ECM)
	5032514800	WIRING FLOWMETER L470
	5313210401	COVER
	5332224100	MOTOR BELT GRINDER
	5513294531	MILK JUG DLSC007
	5332270300	COVER
	5332164700	RUNNER FRAME
	5013252911	CAB CONTATORE-VOLUMETRICO L630(PVC) MCSA
	5313211301	TAPPO SCHIENALE NERO(PC+ABS) (4E)MCSA
	5313215891	GOMMINO ANTIMACCH GREY(EPDM70Z 70SH)MCSA
	5332278900	DISTANZIALE INNESTO NERO (PP) (4E)MCSA
	5913210181	TASTO SELETTORE NERO SRG CHICCHI(4E)MCSA
	5913210211	TASTO IFD NERO SRG"CAPPUCCINO" (4E)MCSA
	6113210111	STAFFA TCO(ACC.C70) (GENERATORE) ECAM
	6113210121	STAFFA SENSORE(ACC.C70) (GENERATORE)ECAM
	5913210191	KEYBOARD
	5913212251	KEYBOARD
	6932102800	BRACKET
	6913210021	E.VALVE BRACKET 2WAY(S.VAP) DEGREASED
	6913210031	E.VALVE BRACKET 3WAY DEGREASED MCSA
	5332279100	CLOSURE
	6913210011	BRACKET
	5032110800	3X1 H05VVF10A L1900 NERO (SHK90°)MCSA
	5313212721	FRONTALE NICCHIA IFD(ABS)SILV-MR(4E)MCSA
	5332286300	HANDLE SILVER
	5332238300	TUBE 90°
001	5332278100	COVER
002	5513211321	COVER
003	5332226300	MEASURING SPOON
004	5332278400	SIDE LEFT
005	7313224431	CLOSURE

006	5332278600	REAR PANEL
007	535714	STOPPER
008	5313211001	KNOB
009	5532145700	TANK
010	5332282000	COVER
011	7313213711	CONTROL PANEL ASSEMBLY
012	7313213731	DOOR ASSY
013	5332278800	COVER
014	5332282600	FRONT PIECE
015	5332282400	SUPPORT
016	5332282500	SUPPORT
017	7313210381	ASS. TANK
018	5332278300	SIDE RIGHT
019	6032120800	CUP PLATE
020	5332266600	FLOAT
021	VI000	SEE TECNICAL INFORMATION
022	5332225000	BOTTOM
023	5332283900	TRAY
024	5132112500	SWITCH
025	5513212801	PIPETTE
026	5332259800	TUBE
027	7313210411	COVER ASSEMBLY
028	7313229411	CARAFE ASSMBLY
029	5513214691	CONTROL BOARD
033	5513227971	COMPLETE GRINDER
034	5332144900	GASKET
035	6013213181	FILTER
037	5513227911	INFUSION KIT
038	5032526800	WIRING TCO
039	5032526900	WIRING TCO
040	5332142200	SUPPORT
041	6132104700	SPRING
042	5132104100	MICROSWITCH
043	7332166600	SLIDER
044	5332142400	BUSH
045	5332142300	BUSH
046	5217100200	SENSOR NTC
047	5313217751	O-RING

048	5332213000	PIN
049	5332148400	VALVE
050	6132106900	SPRING
051	5332149100	O-RING
052	5332139200	FILTER
053	5513227901	GENERATOR
054	5213212381	MOTOR BOARD (ECM)
055	5132110500	MICROSWITCH
056	5213213971	HALL SENSOR
057	5313243071	BELT
058	5513227951	TRANSMISSION KIT
060	5313217701	O-RING D=3,85
061	5313216501	SUPPORT
062	7313219431	VALVE
063	5232103200	PROTECTOR
064	5113211281	PUMP
065	534848	SUPPORT
066	5232104600	SENSOR REED
067	5213212691	POWER BOARD
069	6113210751	INSERT
070	6213210351	NUT
071	6213211521	BUSH
072	6113212051	CONNECTION
073	6113210741	CONNECTION
074	IT0286	SEE TECNICAL INFORMATION
077	5232105000	TCO
078	5213214671	FLOWMETER
079	5513219841	TUBE PTFE L=135 NUT 1BUSHE
080	5313217741	O-RING
081	5332196900	CONNECTION
082	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
083	6132101300	CLIP
084	5332239200	CONNECTOR
087	5513212881	TUBE PTFE DI2-DE4 L=270 2BUSHES
088	6113210021	CLIP
090	5332196800	CONNECTION
091	5513225711	KIT SOLENOID VALVE 3V
092	5513219851	TUBE PTFE L=335 NUT 1BUSHE

093	5513225701	KIT SOLENOID VALVE 2V
095	5332196000	O-RING
096	5513214821	COUPLING CARAFE
098	5332177500	O-RING
100	9824800009	CLIP CLAMP
101	537407	CONNECTION
102	5332142600	HOOK
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW
116	5332139600	STOPPER
117	5332139500	VALVE
118	6132112200	SPRING
119	5332140300	PISTON
120	5313219001	SUPPORT