




PFL105E..



PF70E..





CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT

Aggiornato al/Updated to 27/11/17

Artic./Item	Descrizione/Description		Modello/Model
116008	CUCINA ELETTRICA 4 PIASTRE CON FORNO ELETTRICO VENTILATO 4 HOT PLATES ELECTRIC RANGE WITH FAN ASSISTED ELECTRIC OVEN		PF70E/6/0
Cons./Recom.	Pos./Posit.	Ricambio/Replacement	Prezzo/Price List
	02247000	RC02247000 PORTA FORNO COMPLETA SNACK C/MANIGLIA	234,00
	04	RC01251000 FIANCO DX SNACK	RIGHT SIDE SNACK 32,77
	05	RC00791000 FONDO ELETTRICO 700	BASE EL. 700 33,43
	06	RC00304000 MORSETTO EQUIPOTENZIALE COMPLETO	EQUIPOTENTIAL CONNECTING BLOCK 6,62
	08	RC00241000 PRESSACAVO PG16 CON DADO	CABLE GLAND AND NUT 7,18
	09	RC00194000 MORSETTIERA FV 122 B	CONNECTING BLOCK 9,16
*	10	RC00291000 COMMUTATORE	SWITCH 19,97
*	11	RC01782000 LAMPADA SEGN.NEON FASTON VERDE 230V	GREEN NEON LAMP 230V 6,09
*	12	RC01783000 PORTALAMPADA TRASPARENTE D10	TRANSPARENT LAMP HOLDER D10 5,30
	13	RC02029000 MANOPOLA PCE NERA	BLACK KNOB 9,76
	13	RC02071000 MANOPOLA PCE GRIGIA	GREY KNOB 9,05
	15	RC00655000 CRUSCOTTO PC70E	CONTROL PANEL PC70E 71,28
	16	RC01252000 FIANCO SX SNACK	LEFT SIDE SNACK 32,77
	17	RC00614000 RIPIANO PC70E	SHELF PC70E 211,62
	18	RC00290000 PIASTRA ELETTRICA	HOT PLATE 46,78
*	22	RC00037000 COMMUTATORE MONOFASE	SWITCH 19,64
	24	RC01523000 MANOPOLA ELETTRICA TIMER SNACK GRIGIA	GREY TIMER KNOB
	24	RC01885000 MANOPOLA ELETTRICA TIMER SNACK NERA	BLACK KNOB FOR TIMER LINE SNACK 9,76
	25	RC01524000 MANOPOLA ELETT.TERMOSTATO SNACK GRIGIA	SNACK GREY KNOB
	25	RC01886000 MANOPOLA ELETT.TERMOSTATO SNACK NERA	BLACK KNOB FOR THERMOSTAT LINE SNACK 9,76
*	26	RC00052000 LAMPADA SEGN.NEON FASTON ARANCIO 230V	SIGNAL LAMP 5,19
	27	RC01602000 PIEDE 1"3/4 H250	FOOT 18,98
	30	RC00670000 FIANCO DX PF70/105EG	RIGHT SIDE PF70/105EG 109,78

CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT
Aggiornato al/Updated to 27/11/17

Artic./Item	Descrizione/Description		Modello/Model
116008	CUCINA ELETTRICA 4 PIASTRE CON FORNO ELETTRICO VENTILATO 4 HOT PLATES ELECTRIC RANGE WITH FAN ASSISTED ELECTRIC OVEN		PF70E/6/0
Cons./Recom.	Pos./Posit.	Ricambio/Replacement	Prezzo/Price List
	31	RC00671000 FIANCO SX PF70E/G	LEFT SIDE PF70E/G 49,58
	32	RC01889000 CRUSCOTTO BASE FORNO 60EL SNACK	CONTROL PANEL FOR OVEN 60EL SNACK 18,78
	501	RC02229000 MANIGLIA PSX ALLUMINIO	HANDLE
	502	RC02230000 CRISTALLO PORTA E TNX 60 INOX	ESTERNAL DOOR GLASS
	505	RC02231000 SPEZZONE SILICONE D.5 MM	DOOR RUBBER PART
	506	RC02232000 CRIST PO E 60 TNX NERO	EXTERNAL GLASS OVEN DOOR 77,50
	507	RC02233000 CLIP BLOCCA VETRO INTERNO	DOOR INNER GLASS 4,76
*	508	RC02279000 SQUADRETTA BLOCCA VETRO	BRACKET SUPPORT 24,10
	509	RC02234000 CERNIERA PORTA FRG KG 6,0	DOOR HINGE 27,60
	510	RC02243000 GUARNIZIONE FACCIATA F60	OVEN GASKET 25,58
*	512	RC02280000 RESISTENZA CIRCOLARE 2 SP	FAN HEATING ELEMENT 37,96
	513	RC02281000 SQUADRETTA FISSA FORNO	BRACKET
	514	RC02242000 SQUADRETTA SUPP. CERN. SX PORTA	LEFT HINGE PULLEY
*	521	RC02282000 MOTOVENTILATORE	OVEN MOTOR-FAN 74,98
*	524	RC02283000 LAMPADA CON PORTALAMPADA	LIGHT BULB HOUSING