



Position	Code	description
	9811040850	SCREW
	EE1123	INSTRUCTION BOOK
001	EE1000	STOPPER
002	EE1080	COVER
003	EE1082	STOPPER
004	EE1081	LEVER
005	EE1079	INDICATOR
006	EE1078	COVER
008	EE1077	COVER
009	EE1056	TAP
010	EE1057	KNOB
011	EE1054	TUBE
013	EE1085	SUMP
014	EE1062	CONNECTOR
015	EE1061	CONNECTION
017	EE1060	CASING
018	EE2150	TUBE
019	5132100800	SWITCH
020	EE1073	PUSH BUTTON
021	5132100700	SWITCH
022	EE1063	PLATE
023	EE1015	GASKET
024	EE1121	WARNING LIGHT
025	EE1116	WARNING LIGHT
026	EE1053	BOILER
027	EE1051	DISTRIBUTOR
028	EE1022	GASKET
029	EE1055	BOILER
030	EE1023	GASKET
031	EE1052	DIFFUSER
032	EE1026	THERMOSTAT
033	EE1006	FUSE
034	EE1059	FUSE
035	EE1089	FUNNEL
036	EE1065	BASE
037	ES000	*NOT AVAILABLE
038	EE1076	BOTTOM

039	EE1066	RING
040	EE1067	PLATE
041	EE1070	FUSE
042	EE1120	HEATING Element
043	EE1069	THERMOSTAT
044	EE1071	VALVE
045	EE1091	COVER
046	SL1721920	CONTAINER
047	EE1087	CONTAINER
048	EE1088	COVER
049	EE1009	MEASURING SPOON
050	EE1169	ADAPTER
051	EE1074	PUSH BUTTON