



**CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT**

**Aggiornato al/Updated to 27/11/17**

Artic./Item	Descrizione/Description		Modello/Model
<b>116004</b>	<b>PIANO COTTURA ELETTRICO 4 PIASTRE 4 HOT PLATES ELECTRIC BOILING TOP</b>		<b>PC70E/6/0</b>
Cons./Recom.	Pos./Posit.	Ricambio/Replacement	Prezzo/Price List
	04	RC01251000 FIANCO DX SNACK	RIGHT SIDE SNACK 32,77
	05	RC00791000 FONDO ELETTRICO 700	BASE EL. 700 33,43
	06	RC00304000 MORSETTO EQUIPOTENZIALE COMPLETO	EQUIPOTENTIAL CONNECTING BLOCK 6,62
	07	RC00303000 REGGIFASCETTA	CLAMP SUPPORT 3,97
	08	RC00241000 PRESSACAVO PG16 CON DADO	CABLE GLAND AND NUT 7,18
	10	RC00194000 MORSETTIERA FV 122 B	CONNECTING BLOCK 9,16
	11	RC00518000 PIEDINO H=50 MM	FOOT 5,74
*	12	RC00291000 COMMUTATORE	SWITCH 19,97
*	13	RC01782000 LAMPADA SEGN.NEON FASTON VERDE 230V	GREEN NEON LAMP 230V 6,09
*	14	RC01783000 PORTALAMPADA TRASPARENTE D10	TRANSPARENT LAMP HOLDER D10 5,30
	15	RC02029000 MANOPOLA PCE NERA	BLACK KNOB 9,76
	15	RC02071000 MANOPOLA PCE GRIGIA	GREY KNOB 9,05
	17	RC00655000 CRUSCOTTO PC70E	CONTROL PANEL PC70E 71,28
	18	RC01252000 FIANCO SX SNACK	LEFT SIDE SNACK 32,77
	19	RC00614000 RIPIANO PC70E	SHELF PC70E 211,62
	20	RC00290000 PIASTRA ELETTRICA	HOT PLATE 46,78