



Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1	Abdeckblech	Cover plate	0SL0002
2	Welle	Shaft	0SL0021
3	Lager 6203 2RS	Bearing 6203,2RS	E0SL0131
4	Hülse	Bush	0SL0020
5	Lagerbock	Bearing block	0SL0022
6	Rad	Wheel	0SL2655
7	Zahnrad 3/8 x 7/32 Zoll Z=15	Gear wheel 3/8 x 7/32" Z=15	0SL0024
8	Kette 3/8 Zoll x 7/32 Zoll	Chain 3/8" x 7/32"	0SL0026
9	Schaltnocken	Switch cam	E0SA1062
10	Mikroschalter	Microswitch	0SL0885
11	Winkel	Angle	0SL0397
12	Zahnrad 3/8 x 7/32 Zoll Z=29	Gear wheel 3/8 x 7/32" Z=29	0SL0030
13	Lagerbock UCF204	Bearing block UCF204	0SL0032
14	Halterung z. Rad	Holder f. wheel	0SL2603
15	Elektronik 230V, 1Ph, 50Hz	Electronics 230V, 1Ph, 50Hz	0SA1220
16	Abdeckblech, hinten	Back cover plate	0SL2845
18	Passfeder 5 x 5 x 20 mm	Key 5 x 5 x 20 mm	A0SL0010
19	Passfeder 8 x 7 x 40 mm	Key 8 x 7 x 40 mm	0SL3410
20	Welle	Shaft	0SA1019
21	Getriebe	Gear	0SL3186
22	Motor 230 V, 1 Ph, 50 Hz	Motor 230 V, 1 Ph, 50 Hz	0SL3212
23	Zugentlastung PG11	Strain relief PG11	0SL1668
24	Anschlusskabel 230V, 1Ph, GND	Power cord 230V, 1Ph, GND	A0SL1671
25	Fuß	Base	0SL3352*
	Fuß	Base	0SL3361
26	Gehäuse	Housing	0SL3355
27	Gehäuse z. Schalter	Housing f. switch	0SL0937
28	Dichtung z. Gehäuse	Gasket f. housing	0SL0396
29	Schalter "STOP"	Switch "STOP"	0SL0807
30	Schalter "START"	Switch "START"	0SL1049
31	Zahnrad 8 x 3 Z=85	Gear wheel 8 x 3 Z=85	0SL0057
32	Kette 8 x 3	Chain 8 x 3	0SL0058
33	Stange	Rod	0SL3370
34	Achse klein	Small axle	0SL0014
35	Lagerbock	Bearing block	0SL0016
36	Sicherungsring D 17	Locking ring D 17	0SL0017
37	Mutter z. Schaltnocken	Nut f. switch cam	0SL0036



Teignetmaschine 18 kg, 22L
Artikel-Nr.: 101955

Ersatzteilliste
07.03.2016

