

Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1	Abdeckblech	Cover plate	0SL0062
2	Welle	Shaft	0SL0076
3	Kette 1/2 x 5/16 Zoll (38)	Chain 1/2" x 5/16" (38)	0SL0079
4	Zahnrad 1/2 x 5/16 Zoll, Z 15	Gear wheel 1/2" x 5/16", Z 15	0SL3265
5	Hülse	Bush	0SL3264
6	Lager 6205Z	Bearing 6205Z	A0SL0118
7	Lagerbock	Bearing block	0SL3261
8	Schaltnocken	Switch cam	0SL0035
9	Mutter z. Schaltnocken	Nut f. switch cam	0SL0036
10	Mikroschalter	Microswitch	0SL0885
11	Winkel	Angle	0SL0397
12	Zahnrad 1/2 x 5/16 Zoll Z=29	Gear wheel 1/2 x 5/16" Z=29	0SL0084
13	Lagerbock UCF205	Bearing block UCF205	0SL0086
14	Halterung z. Rad	Holder f. wheel	E0SL2605R0
15	Elektronik 230V, 1Ph, 50Hz	Electronics 230V, 1Ph, 50Hz	0SA1220
16	Abdeckblech	Cover plate	E0SL2849R0
17	Passfeder 8 x 7 x 20	Key 8 x 7 x 20	0SL2057
18	Passfeder 6 x 6 x 25	Key 6 x 6 x 25	0SL1056
19	Passfeder 8 x 7 x 40 mm	Key 8 x 7 x 40 mm	0SL3410
20	Welle	Shaft	0SA1020
21	Getriebe	Gear	0SL3338
22	Motor 230 V, 1 Ph, 50 Hz	Motor 230 V, 1 Ph, 50 Hz	0SL3214
23	Zugentlastung PG11	Strain relief PG11	0SL1668
24	Anschlusskabel 230V, 1Ph, GND	Power cord 230V, 1Ph, GND	A0SL1671
25	Fuß	Base	0SL3361
26	Gehäuse	Housing	0SL3356
27	Gehäuse z. Schalter	Housing f. switch	0SL0937
28	Dichtung z. Gehäuse	Gasket f. housing	0SL0396
29	Schalter "STOP"	Switch "STOP"	0SL0807
30	Schalter "START"	Switch "START"	0SL1049
31	Zahnrad 3/8 x 7/32 Zoll Z=85	Gear wheel 3/8 x 7/32" Z=85	0SL0100
32	Kette 3/8 Zoll x 7/32 Zoll	Chain 3/8" x 7/32"	0SL0102
33	Stange	Rod	0SL3371
34	Achse, klein	Small axle	0SL0072
35	Lager	Bearing	0SL1799
36	Lagerbock	Bearing block	0SL0074
37	Lager 3204	Bearing 3204	0SL0103



Teignetmaschine 38 kg, 42L
Artikel-Nr.: 101957

Ersatzteilliste
08.03.2016

