



Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1	Abdeckblech	Cover plate	0SL3334
2	Welle	Shaft	0SL0076
3	Kette 1/2 Zoll x 5/16 Zoll	Chain 1/2" x 5/16"	0SL3365
4	Hülse	Bush	0SL3264
5	Lager 6205Z	Bearing 6205Z	A0SL0118
6	Lager 6005 2RS	Bearing 6005 2RS	E0SL0202
7	Lagerbock	Bearing block	0SL3261
8	Schaltnocken	Switch cam	0SL0035
9	Mutter z. Schaltnocken	Nut f. switch cam	0SL0036
10	Mikroschalter	Microswitch	0SL0885
11	Winkel	Angle	0SL0397
12	Zahnrad 1/2 x 5/16 Zoll Z=29	Gear wheel 1/2 x 5/16" Z=29	0SL0084
13	Lagerbock UCF205	Bearing block UCF205	0SL0086
14	Abdeckblech oben	Top cover plate	0SL3335
15	Elektronik	Electronics	E0SA1210
16	Abdeckblech	Cover plate	0SL3367
17	Zahnrad 1/2 x 5/16 Zoll, Z 15	Gear wheel 1/2" x 5/16", Z 15	0SL3265
18	Passfeder 6 x 6 x 25	Key 6 x 6 x 25	0SL1056
19	Passfeder 8 x 7 x 40 mm	Key 8 x 7 x 40 mm	0SL3410
20	Welle	Shaft	0SA1024
21	Getriebe	Gear	0SL3338
22	Motor 400V, 3Ph, 50Hz (2 Stufen)	Motor 400V, 3Ph, 50Hz (2 stages)	E0SL3311
23	Zugentlastung PG11	Strain relief PG11	0SL1668
24	Anschlusskabel 3Ph, GND	Power cord 3Ph, GND	A0SL1841
25	Fuß	Base	0SL3361
26	Gehäuse	Housing	0SL3332
27	Gehäuse z. Schalter	Housing f. switch	0SL0937
28	Dichtung z. Gehäuse	Gasket f. housing	0SL0396
29	Schalter "STOP"	Switch "STOP"	0SL0807
30	Schalter "START"	Switch "START"	0SL1049
31	Zahnrad 3/8 x 7/32 Zoll Z=85	Gear wheel 3/8 x 7/32" Z=85	0SL0100
32	Kette	Chain	0SL2686
33	Stange	Rod	0SL3371
34	Achse, klein	Small axle	0SL0072
35	Lager	Bearing	0SL1799
36	Lagerbock	Bearing block	0SL0074
38	Sicherungsring D 20	Locking ring D 20	0SL0075



Teigknetmaschine 25kg/32L Plus
Artikel-Nr.: 101868

Ersatzteilliste
14.12.2017

Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
39	Knethaken	Dough hook	0SA1030
40	Halterung z. Rad	Holder f. wheel	0SL2604
41	Buchse	Bush	0SL1090
42	Rad	Wheel	0SL2655
43	Bolzen	Pin	0SL2625
44	Bolzen	Pin	0SL2630
45	Gehäusekasten oben	Upper housing element	0SL3333
47	Sicherungsring D 25	Locking ring D 25	0SL161
48	Passfeder 8 x 7 x 18	Fitting spring 8 x 7 x 18	E0SL3408
49	Schutzblech	Protection plate	E0SL4112
50	Lagerbock	Bearing block	0SL2627
51	Deckel z. Schüssel	Lid f. bowl	0SA1006
52	Schüssel	Bowl	0SA1170
53	Arretierungsschraube	Locking screw	0SL2623
54	Dichtung	Sealing	0SL1034
55	Platte	Plate	0SL2637
56	Flansch	Flange	0SL2621
57	Halteplatte	Supporting plate	0SL2636
58	Feder	Spring	0SL2668
59	Lagerbock komplett	Bearing block complete	0SA1047
60	Kupplung	Coupling	0SL3206
61	Kupplungsbolzen	Coupling shaft	0SL3204
62	Kettenschloss 1/2 Zoll x 5/16 Zoll	Chain joint 1/2" x 5/16"	0SL1632
63	Kettenschloss 3/8 Zoll x 7/32 Zoll	Chain joint 3/8" x 7/32"	0SL1629
64	Lenkrollen 4TKM	Wheel set, 4 pieces	101863
65			
66	Lagerbock, komplett	Bearing block, complete	0SA1800
67	Mikroschalter	Microswitch	A0SL1401
69	Achse	Axle	0SL3266
70	Spirale	Spiral	0SL0069
71	Getriebemotor 400V, 3Ph, 50Hz	Gearmotor 400V 3Ph 50Hz	E0SL3404
72	Abdeckung, Edelstahl	Cover, stainless steel	0SL3419
73	Schalter	Switch	0SL0054
74	Schaltnocken	Switch cam	0SL4090
75	Bügel	Clamp	0SL4089
76	Mikroschalter	Microswitch	0SA1140
77	Sicherung	Fuse	0SL4119



Teigknetmaschine 25kg/32L Plus
Artikel-Nr.: 101868

Ersatzteilliste
14.12.2017

